

OPERATING & SAFETY GUIDE

This appliance is only for professional use by a qualified operator



Salamander Grill Product Code 601071

230v 2.8kw 13amp

A full copy of the EHA Code of Practice regarding the safe hire of Electrical Equipment is available on request

GENERAL SAFETY ADVICE

Allens will have prepared, checked and delivered this appliance to you in accordance with the Event Hire Association (EHA) Code of Practice for Electrical Testing.

Electrical equipment is required to be properly maintained so as to prevent danger to the user.

It is our policy to inspect every electrical appliance before re-hire. This is done by an electrically qualified person trained in PAT Testing. This combined inspection and test includes:

- Visual Inspection
- Earth continuity tests (for Class I equipment)
- Insulation resistance testing (which can be replaced with protective conductor/touch current measurement)
- Flash Testing (or Hi-Pot testing)
- No load (run) test
- Polarity check (extension or detachable lead sets only), and
- Functional tests

The results of each test are recorded and are kept as records for future inspection.

OPERATING INSTRUCTIONS

- 1. Raise element hood to highest position.
- 2. Switch on Salamander on/off switch will illuminate.
- 3. Warm up time is 10 15 minutes.
- 4. Place plates or dishes on grill tray.
- 5. Adjust height of hood to desired position for food.
- 6. Raise hood to maximum height before removing any plates or dishes.
- 7. Ensure sliding grill tray is always fully pushed back after use.
- 8. The audible timer does not control the power.
 Unit must be switched off at on/off switch.

WARNING

- This appliance should not be operated with hood in lowest position for longer than 30 minutes.
- Make sure that food does not come into contact with the heating element to prevent soiling and damage.

SAFE USE

The safe use of hire equipment is the sole responsibility for the hirer once the items are collected or arrive on site.

Allens staff are not allowed to install equipment on site, and you are not permitted to make any alterations to the appliance or its connectors in any way.

If in any doubt please ask an Allens advisor for advice on 020 8574 9600 or a qualified electrician.

- Never use the equipment in a poorly ventilated space or near combustible materials.
- Keep all children, animals and bystanders away from the appliances whilst in operation.
- Ensure the floor of the work area is flat, free from trip hazards and non-slip.
- Keep a bucket of water nearby to treat burns.
- Use CO₂ extinguisher to hand in case of and emergency.
- Wear suitable protective clothing, such as an apron, overall and hat. Use kitchen gloves for handling utensils to protect from burns.
- Allow the appliance to cool fully before touching or cleaning.