

## OPERATING & SAFETY GUIDE

This appliance is only for professional use by a qualified operator



**Double Stacked Digital Gastronome Oven**  
Product Code 601073

240v 3.1kw x 2 2.9amp x 2

A full copy of the EHA Code of Practice  
regarding the safe hire of Electrical Equipment  
is available on request

### GENERAL SAFETY ADVICE

Allens will have prepared, checked and delivered this appliance to you in accordance with the Event Hire Association (EHA) Code of Practice for Electrical Testing.

Electrical equipment is required to be properly maintained so as to prevent danger to the user.

It is our policy to inspect every electrical appliance before re-hire. This is done by an electrically qualified person trained in PAT Testing. This combined inspection and test includes:

- Visual Inspection
- Earth continuity tests (for Class I equipment)
- Insulation resistance testing (which can be replaced with protective conductor/touch current measurement)
- Flash Testing (or Hi-Pot testing)
- No load (run) test
- Polarity check (extension or detachable lead sets only), and
- Functional tests

The results of each test are recorded and are kept as records for future inspection.

### OPERATING INSTRUCTIONS

Please see Full Operating Instructions

### WARNINGS

- The Vent at the rear of the oven must NOT be obstructed.
- Check the electricity supply is correct to as shown on the Technical Data Plate (front right hand corner of the oven side panel).
- Some parts of the oven will become VERY HOT during use and could cause burns if touched.
- Take care opening the oven door during baking. Let hot air/steam escape before removing or replacing food. The steam could cause steam burns.

### SAFE USE

The safe use of hire equipment is the sole responsibility for the hirer once the items are collected or arrive on site.

Allens staff are not allowed to install equipment on site, and you are not permitted to make any alterations to the appliance or its connectors in any way.

If in any doubt please ask an Allens advisor for advice on 020 8574 9600 or a qualified electrician.

- Never use the equipment in a poorly ventilated space or near combustible materials.
- Keep all children, animals and bystanders away from the appliances whilst in operation.
- Ensure the floor of the work area is flat, free from trip hazards and non-slip.
- Keep a bucket of water nearby to treat burns.
- Use CO<sub>2</sub> extinguisher to hand in case of and emergency.
- Wear suitable protective clothing, such as an apron, overall and hat. Use kitchen gloves for handling utensils to protect from burns.
- **Allow the appliance to cool fully before touching or cleaning.**