

OPERATING & SAFETY GUIDE

This appliance is only for professional use by a qualified operator



Gas Hot Cupboard
Product Code 602013

A Full EHA Code of Practice for the "Safe Use of LPG" is available on our website www.allenshire.co.uk. Please go to our Gas Appliances and BBQs catalogue page to download

Gas Hot Cupboard

Pilot lighting instructions

1. Make sure the appliance is turned OFF at the service cock.
2. Use separate instructions provided for connecting the LPG cylinder to this appliance.
3. Turn the gas on at the service cock.
4. The lower control on the control panel operates the Hot Cupboard.
5. Turn the control knob anti-clockwise to the ignition position marked '□' and depress fully. While keeping the control knob fully depressed, press the black ignition button several times until the pilot burner is lit. (This is visible by opening the right-hand door, and looking through the first hole in the skirt of the base or fourth hole on 1900 & 2200 models.)
6. Keep the control knob depressed for a further 15 seconds and then release it, checking that the pilot burner remains lit.
7. If the pilot burner has extinguished, turn the control knob fully clockwise to the position marked '□' or OFF, push in fully and release. Wait 3 minutes before repeating 5. & 6. above.

GENERAL SAFETY ADVICE

Allens will have prepared, checked and delivered this appliance to you in accordance with the Code of Practice entitled "Safe Use of LPG: Portable and Transportable Equipment in the Hire Industry" (LPG Code) launched in October 2013 by the Event Hire Association (EHA).

PLEASE READ THESE INSTRUCTIONS CAREFULLY. THERE IS A RISK OF INJURY IF YOU DO NOT FOLLOW THE INSTRUCTIONS IN THIS GUIDE.

These instructions are provided so you can familiarise yourself with proper and safe operation of this appliance but are not a substitute for being conversant with duties as hirer under the LPG Code.

The safe use of hired gas equipment is the sole responsibility of the hirer once the items are collected or arrive on site. Allens staff are not allowed to install equipment on site and you are not permitted to make any alterations to the appliance or its connectors in any way.

If in any doubt please ask an Allens advisor for advice on 020 8574 9600 or a gas safe engineer conversant with the LPG Code.

Never use the equipment in a poorly ventilated space. Keep all children, animals and bystanders away from the work area. Ensure the floor of the work area is free from trip hazards and non-slip.

Keep a bucket of water nearby to treat burns. Use a CO2 extinguisher in case of fire. Wear suitable clothing, such as an apron, overall and hat. Use kitchen/BBQ gloves to handle utensils. Tie back long hair.

Allow the appliance to cool fully before touching or cleaning.

Lighting in the event of Igniter failure

If the igniter fails for any reason, the appliance can still be used. Follow the standard instructions; however instead of pressing the igniter button, insert a lighted taper (minimum length 250mm/10") through the pilot burner observation hole and ignite the pilot burner.

NOTE: If the gas control has been off for an extended period, the pilot burner may take 30 seconds to light, as the air needs to be purged from the pilot burner supply pipe work. Turn to the number '1' to achieve minimum temperature.

Burner Lighting Instructions

When the pilot has been successfully lit follow the following instructions to operate the Hot Cupboard.

1. To increase the temperature, turn the control knob fully anti-clockwise from the ignition position marked '□' to the number '7' to achieve maximum temperature. Do not turn the control knob whilst it is depressed.
2. To decrease temperature, turn the control knob clockwise from the number '7'.